

Model 5065

Calculator Features:

- Enter BTU to find Kilowatts per Hour
- Enter Kilowatts per Hour to find BTU
- Parallel Resistance
- NEC Table Number displayed when performing Wire Size calculations (2005/2008)



**Includes:
Armadillo
Gear®
Protective
Hard Case**

Shock absorbing protective hard case with soft-grip and tough 360° flip-top cover



CALCULATED INDUSTRIES®

Putting answers at your fingertips since 1978

4840 Hytech Drive
Carson City, NV 89706
1-775-885-4900
Fax: 1-775-885-4949
Visit our website at:
www.calculated.com

ELECTRICCALC® PRO

Electrical Code Calculator

Compliant with 2008, 2005, 2002, 1999 and 1996 NEC®


Electrical Contractors • Designers • Engineers • Electricians • Maintenance Inspectors • Planners • Builders • Lighting Specialists



Wire Sizes; Integrated Voltage Drop; Conduit Sizing



Motor Full-Load AMPs; Fuse and Breaker Sizes



NEC® Tables Show for Wire Size Calculations



Service and Equipment Grounding Conductor Sizes

The **ElectricCalc Pro** is the world's most complete Code-based electrical calculator. Solve electrical calculations in seconds; answers conform to current NEC®. It's a complete electrical reference tool that will save time, trouble and money. *Update to future code revisions with an easy-to-install kit.*

Wire Types — Calculate wires in Raceways and cross-sectional wire area.

Conduit Size — Find conduit sizes based on total area of entered wire types and sizes.

HPmotor — Enters or calculates motor horsepower.

Dual Element Fuse — Calculates minimum amp rating for Dual Element Fuse, full-load current percent multiplier.

Hpth — Enter or calculate theoretical horsepower.

Set — Accesses secondary functions.

Inverse Time — Calculate the minimum amp rating for an Inverse Time Breaker.

Voltage Drop — Enter or calculate voltage drop and actual percentage.

Overload — Displays the overload amperage based on the full-load current on motor nameplate.

Length — Enters or calculates the length of a run for voltage drop computation.

Wire Sizes — Enter or calculate wire sizes based on ampacity and voltage drop for Ground, Derated, Parallel and Motor, etc.

Preferences — Used to set default settings or modes, including NEC Code Year.

Work In — Enter or calculate electrical functions.



Dedicated Keys and Functions Make It Easy To Use!